



## ROBOTC Reset Bluetooth Instructions – NXT Brick


*Note: Only available with ROBOTC firmware*




Step 1: Navigate to the “Bluetooth” menu on the main menu on the NXT. Press the Orange button to go into the “Bluetooth” sub-menu.



Step 2: Navigate to the “Reset” command from the “Bluetooth” sub-menu on the NXT. Press the Orange button to enter the Reset command.



Step 3: Navigate to the “check mark” to reset the internal Bluetooth on the NXT. Press the Orange button to start the process.



Step 4: “Reset Bluetooth” will appear. Once the NXT menu has returned, you are ready to re-pair your NXT.